



**COMPACTORS- ROAD AND REFUSE- REPLACEMENT SEATS**

ALPHA 160					
PROPAC SD 100					
PROPAC SD 115					
PROPAC SD 120					
PROPAC SD 170					
SD 180					
DD 16					
DD 18					
DD 20					
DD 22					
DD 24					
DD 32					
DD 74					
RTR 220/250					
PUMA 169 AV - EV - TV					
<b>AMMAN YANMAR Compactors</b>					
<b>MODEL</b>	<b>OPTION 1</b>	<b>OPTION 2</b>	<b>OPTION 3 (Air Op</b>	<b>OEM SEAT</b>	<b>COMMENTS</b>
RX2900					
AV12					
AV16					
AV20					
AV16K					
AV23					
AV23K					
AV26					
AV26K					
AV32					
AV32K					
AV33					
AV40					
AV40K					
AV32P					
AV75					
AV75K					
AV95					
AV95K					
AS135					
RW1800SPT					
RX3000SPT					
AC70-2					
AC110-2					
AC130-2					
AC190-2					
<b>BARFORD Compactors</b>					
<b>MODEL</b>	<b>OPTION 1</b>	<b>OPTION 2</b>	<b>OPTION 3 (Air Op</b>	<b>OEM SEAT</b>	<b>COMMENTS</b>
<b>1407</b>	1407	7020 or 7050		DS85	Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").
<b>BENFORD Compactors</b>					
<b>MODEL</b>	<b>OPTION 1</b>	<b>OPTION 2</b>	<b>OPTION 3 (Air Op</b>	<b>OEM SEAT</b>	<b>COMMENTS</b>
<b>TV75</b>	1400P	1200 or 1500		MSG20	
<b>TV120</b>	1400P	1200 or 1500		MSG20	
<b>TV800</b>	1400P	1200 or 1500		MSG20	

<b>BITELLI Compactors</b>					
MODEL	OPTION 1	OPTION 2	OPTION 3 (Air Op	OEM SEAT	COMMENTS
	906	706		DS 44 type CDS	
				DS 44 type CDS	
				DS 44 type CDS	
<b>BOMAG Compactors</b>					
MODEL	OPTION 1	OPTION 2	OPTION 3 (Air Op	OEM SEAT	COMMENTS
172D-2	1400P	1200 or 1500		MSG20	Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").
BW60S	1400P	1200 or 1500		MSG20	Ditto
BW75ADL	1400P	1200 or 1500		MSG20	Ditto
BW90AC	1400P	1200 or 1500		MSG20	Ditto
BW100AC	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW120AC	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW125AC	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW135AC	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW138AC	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW144AC	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW151AC	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW161AC	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW164AC	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW174AC	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW80AD	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW80ADH	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW90AD	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW100AD	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW120AD	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW80ADS	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW100ADS	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW125ADH	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW135AD	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW138AD	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW170AD	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW174AD	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW180AD	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW184AD	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW141AD	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW144AD	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW151AD	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW154AD	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW161AD	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW164AD	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW202AD	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW124DH	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW124PDH	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW124PDB	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW145D	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW145DH	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW145PDH	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW177D	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW177DH	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW177PDH	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW178D	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW178DH	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW178PDH	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW179D	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW179DH	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW179ODH	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW211D	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW211PD	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW212D	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW212PD	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW213D	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW213PD	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW214D	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW214PD	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW214DH	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW214PDH	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW216D	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW217D	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW216DH	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW216PDH	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW219DH	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW219PDH	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW225D	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
BW225PD	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto
	1407	7020 or 7050	D7060 or D8070	DS85/20	Ditto

<b>CATERPILLAR Compactors</b>					
MODEL	OPTION 1	OPTION 2	OPTION 3 (Air Option)	OEM SEAT	COMMENTS
CS-431C	1407	7020 or 7050	D7060 or D8070	Milsco	Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").
CS-433C	1407	7020 or 7050	D7060 or D8070	Milsco	Ditto
CP-433C	1407	7020 or 7050	D7060 or D8070	Milsco	Ditto
CS-531C	1407	7020 or 7050	D7060 or D8070	Milsco	Ditto
CS-533C	1407	7020 or 7050	D7060 or D8070	Milsco	Ditto
CP-533C	1407	7020 or 7050	D7060 or D8070	Milsco	Ditto
CS-563D	1407	7020 or 7050	D7060 or D8070	Milsco	Ditto
CP-563D	1407	7020 or 7050	D7060 or D8070	Milsco	Ditto
CS-583D	1407	7020 or 7050	D7060 or D8070	Milsco	Ditto
CB-214D	1407	7020 or 7050	D7060 or D8070	Milsco	Ditto
CB-224D	1407	7020 or 7050	D7060 or D8070	Milsco	Ditto
CB-225D	1407	7020 or 7050	D7060 or D8070	Milsco	Ditto
CB-334D	1407	7020 or 7050	D7060 or D8070	Milsco	Ditto
CB-335D	1407	7020 or 7050	D7060 or D8070	Milsco	Ditto
CB-424C	1407	7020 or 7050	D7060 or D8070	Milsco	Ditto
CB-534C	1407	7020 or 7050	D7060 or D8070	Milsco	Ditto
CB-535B	1407	7020 or 7050	D7060 or D8070	Milsco	Ditto
CB-544	1407	7020 or 7050	D7060 or D8070	Milsco	Ditto
CB-545	1407	7020 or 7050	D7060 or D8070	Milsco	Ditto
CB-634C	1407	7020 or 7050	D7060 or D8070	Milsco	Ditto
PF-300B	1407	7020 or 7050	D7060 or D8070	Milsco	Ditto
PS-300B	1407	7020 or 7050	D7060 or D8070	Milsco	Ditto
PS500	1407	7020 or 7050	D7060 or D8070	Milsco	Ditto
<b>DEMAG Road rollers</b>					
MODEL	OPTION 1	OPTION 2	OPTION 3 (Air Option)	OEM SEAT	COMMENTS
	1407	7020 or 7050	D7060 or D8070	DS85/90	Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").
<b>DYNAPAC Road rollers</b>					
MODEL	OPTION 1	OPTION 2	OPTION 3 (Air Option)	OEM SEAT	COMMENTS
CA251D	1407	7020 or 7050	D7060 or D8070		Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").
CA151	1407	7020 or 7050	D7060 or D8070		Ditto
CA151D	1407	7020 or 7050	D7060 or D8070		Ditto
CA30D	1407	7020 or 7050	D7060 or D8070		Ditto
<b>FINNPAVE Road rollers</b>					
MODEL	OPTION 1	OPTION 2	OPTION 3 (Air Option)	OEM SEAT	COMMENTS
<b>HAMM Compactors</b>					
MODEL	OPTION 1	OPTION 2	OPTION 3 (Air Op	OEM SEAT	COMMENTS
4011D	1407	7020 or 7050	D7060 or D8070	DS85	Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").
2311D	1407	7020 or 7050	D7060 or D8070	DS85	Ditto
3012D	1407	7020 or 7050	D7060 or D8070	DS85	Ditto
DV62.2	1407	7020 or 7050	D7060 or D8070	DS85	Ditto
DV62.1	1407	7020 or 7050	D7060 or D8070	DS85	Ditto
DV82.1	1407	7020 or 7050	D7060 or D8070	DS85	Ditto
DV82.2	1407	7020 or 7050	D7060 or D8070	DS85	Ditto
DV8K	1407	7020 or 7050	D7060 or D8070	DS85	Ditto
<b>HYPAC Compactors</b>					
MODEL	OPTION 1	OPTION 2	OPTION 3 (Air Op	OEM SEAT	COMMENTS
C747B					Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").
C852B					Ditto
C830D					Ditto

<b>INGERSOLL RAND - COMPACTORS</b>					
MODEL	OPTION 1	OPTION 2	OPTION 3 (Air Option)	OEM SEAT	COMMENTS
SD-100	7020 or 7050	1407 or 1420	D7060 or D8070		Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").
SD-115	7020 or 7050	1407 or 1420	D7060 or D8070		Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").
SD150	7020 or 7050	1407 or 1420	D7060 or D8070		Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").
SD175	7020 or 7050	1407 or 1420	D7060 or D8070		Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").
SD180	7020 or 7050	1407 or 1420	D7060 or D8070		Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").
DD-70	7020 or 7050	1407 or 1420	D7060 or D8070		Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").
DD90HF	7020 or 7050	1407 or 1420	D7060 or D8070		Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").
325				Milsco	Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").
473				ISRI	Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").
<b>HYPAC COMPACTORS</b>					
MODEL	OPTION 1	OPTION 2	OPTION 3 (Air Option)	OEM SEAT	COMMENTS
C747B	7020 or 7050	1407 or 1420	D7060 or D8070		Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5"). May need hight riser kit SA19178
C852B	7020 or 7050	1407 or 1420	D7060 or D8070		Ditto
C830D	7020 or 7050	1407 or 1420	D7060 or D8070		Ditto
<b>LEBRERO Road rollers</b>					
MODEL	OPTION 1	OPTION 2	OPTION 3 (Air Op	OEM SEAT	COMMENTS
<b>PROTEC Road rollers</b>					
MODEL	OPTION 1	OPTION 2	OPTION 3 (Air Op	OEM SEAT	COMMENTS
<b>107HD</b>	906	1006		DS44	Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5"). May need hight riser kit SA19178
<b>111PD</b>	906	1006		DS44	Ditto
<b>114</b>	906	1006		DS44	Ditto
<b>116HD</b>	906	1006		DS44	Ditto
<b>119</b>	906	1006		DS44	Ditto
<b>WATANABE Road rollers</b>					
MODEL	OPTION 1	OPTION 2	OPTION 3 (Air Option)	OEM SEAT	COMMENTS
WP902	906	1006			
<b>REFUSE COMPACTORS</b>					
<b>ATLAS -Refuse Compactors</b>					
MODEL	OPTION 1	OPTION 2	OPTION 3 (Air Option)	OEM SEAT	COMMENTS
AW1070	7020 or 7050	1407 or 1420	D7060 or D8070		Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").
AW1190	7020 or 7050	1407 or 1420	D7060 or D8070		Ditto
<b>CATERPILLAR -Refuse Compactors</b>					
MODEL	OPTION 1	OPTION 2	OPTION 3 (Air Option)	OEM SEAT	COMMENTS
<b>815F</b>	7020 or 7050	1407 or 1420	D7060 or D8070	Milsco	Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").
<b>816F</b>	7020 or 7050	1407 or 1420	D7060 or D8070	Milsco	Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").
<b>825G</b>	7020 or 7050	1407 or 1420	D7060 or D8070	Milsco	Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").
826G	7020 or 7050	1407 or 1420	D7060 or D8070	Milsco	Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").
836	7020 or 7050	1407 or 1420	D7060 or D8070	Milsco	Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").
980G	7020 or 7050	1407 or 1420	D7060 or D8070	Milsco	Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").
<b>KOMATSU Refuse Compactors</b>					
MODEL	OPTION 1	OPTION 2	OPTION 3 (Air Option)	OEM SEAT	COMMENTS
CD300	7020 or 7050	1407 or 1420	D7060 or D8070		Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5"). May need hight riser kit SA19178
WF450/T	7020 or 7050	1407 or 1420	D7060 or D8070		Ditto
WF550/T	7020 or 7050	1407 or 1420	D7060 or D8070		Ditto