



RECOMMENDED REPLACEMENT SEATS

CATERPILLAR Pipe layer					
MODEL	OPTION 1	OPTION 2	OPTION 3 (Air Option)	OEM SEAT	Comments
561M	7050	D8060	D8087	Sears/CAT Contour	Installation kit SA19236.901 required. This kit accommodates all bolt patterns up to 355 wide x 402mm (14 x15.8").
572R	7050	D8060	D8087	KAB	Installation kit SA19236.901 required. This kit accommodates all bolt patterns up to 355 wide x 402mm (14 x15.8").
583R	7050	D8060	D8087	KAB	Installation kit SA19236.901 required. This kit accommodates all bolt patterns up to 355 wide x 402mm (14 x15.8").
589	7050	D8060	D8087	KAB	Installation kit SA19236.901 required. This kit accommodates all bolt patterns up to 355 wide x 402mm (14 x15.8").